



AUTOMOTIVE ACCESSORY
MANUFACTURE & DISTRIBUTION

AIRPLEX INDUSTRIES LTD
21 Saleyards Road, Otahuhu, Auckland 1062, New Zealand
PO Box 11286, Ellerslie, Auckland 1542 New Zealand
PH +64 (9) 276-9826 Fax +64 (9) 276-9836
info@airplex.co.nz www.airplex.co.nz

FITTING INSTRUCTIONS FIT1005

PLEASE READ INSTRUCTIONS COMPLETELY BEFORE INSTALLATION

**LDV T60 - WITH SPORT
BAR 2017+**

**PART NUMBER:
TC130**

MADE IN NEW ZEALAND

Components:



1. Insert the Front Blocks into the Front Rail. Place the Front Rail in front of the sports bar. It should rest up against the front of the sports bar.
2. Drill through the pre-drilled holes in the Front Rail. (through the bedliner & wellside with a 3mm drill bit).
3. Spray rust preventative ('CRC Soft Seal' or similar) into the freshly drilled holes.
4. Firmly secure with supplied black screws to secure the Front Rail to the vehicle.
5. Locate each 'Side Rail – Front' rails in between both sides of the sports bar. Ensure rail “notches” are located towards the inside.
6. Place the front cross-bar (marked 'F') between the Side Rails locating each end into the side rail notches.



7. With 2 people hold firmly on each side rail so the cross-bar is not loose. Make sure both side rails have the same gap from the edge of the inner bed liner to the side rail) and with the 3mm drill bit mark the Bed liner through the pre-drilled holes in the side rails. Remove the rails and drill the holes through bed liner and wellside.
8. Spray the freshly drilled holes with rust preventative (CRC Soft Seal or similar)
9. Install the side rails using supplied screws. Re-fit the cross-bar between side rails.
10. Place 'Side Rail – Rear' rails marked left and right behind the sports bar. Note the notches on the inside. These cross-bar/rail notches are set toward the front.
11. Assemble the 'Rear Rail and large Blocks, and fit to 'Side Rail Rear
12. Fit the Rear cross-bar & Middle cross-bar into the 2 side rail notches
13. Ensure the open distance between Front & Rear Bar is 1480mm. See image below.



14. Repeat steps 7,8,9 and 10 to secure these side rails.
15. Now you are ready to clip the vinyl cover into place.